

Manual

ASUS IoT

X621ES-IM-AA
X641ES-IM-AA
X642ES-IM-AA

**3.5" SBC, Elkhart Lake platform, Processor, DDR4 SO DIMM,
DP, HDMI, LVDS, Dual LAN, Multiple COM, 9-36V DC input**

FORTEC
UNITED STATES



FORTEC
INTEGRATED



FORTEC
UNITED KINGDOM



The information contained in this document has been carefully researched and is, to the best of our knowledge, accurate. However, we assume no liability for any product failures or damages, immediate or consequential, resulting from the use of the information provided herein. Our products are not intended for use in systems in which failures of product could result in personal injury. All trademarks mentioned herein are property of their respective owners. All specifications are subject to change without notice.



X621ES-IM-AA

X641ES-IM-AA

X642ES-IM-AA

User Manual



E22700

First Edition

January 2024

COPYRIGHT INFORMATION

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER INC. ("ASUS").

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Copyright © 2024 ASUSTeK COMPUTER INC. All Rights Reserved.

LIMITATION OF LIABILITY

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for no more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages resulted from omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

SERVICE AND SUPPORT

Visit our multi-language website at <https://www.asus.com/support/>

Contents

About this manual.....	5
Conventions used in this manual.....	6
Package contents	7

Chapter 1: Specifications Summary

Specifications Summary.....	10
-----------------------------	----

Chapter 2: Product Introduction

2.1 Before you proceed	14
2.2 Motherboard layout.....	15
2.3 System memory.....	17
2.4 Onboard jumpers & switches.....	18
2.5 Internal connectors	21
2.6 I/O connectors.....	35

Chapter 3: Upgrading your Single Board Computer

3.1 Installing memory modules	39
3.2 Installing a 2.5-inch storage device	40
3.3 Installing an M.2 SSD.....	41
3.4 Installing a nano SIM card.....	42
3.5 Installing a wireless card.....	43
3.6 Installing an M.2 B-key module.....	44
3.7 Installing a heatsink.....	45
3.8 Installing a heat spreader.....	46

Chapter 4: BIOS Setup

4.1 Getting to know your BIOS.....	50
4.2 BIOS setup program	51
4.3 Main Menu.....	53
4.3.1 System Date [Day xx/xx/xxxx].....	53
4.3.2 System Time [xx:xx:xx].....	53

4.4	Advanced menu	54
4.4.1	PCH-FW Configuration	55
4.4.2	Trusted Computing	56
4.4.3	CPU Configuration	57
4.4.4	Graphics Configuration	59
4.4.5	Super IO Configuration	60
4.4.6	Serial Console Redirection	61
4.4.7	SATA Configuration	64
4.4.8	Network Stack Configuration	65
4.4.9	USB Configuration	66
4.4.10	NVMe Configuration	67
4.4.11	Onboard Devices Configuration	68
4.4.12	APM Configuration	70
4.4.13	Watchdog Timer	71
4.4.14	EZ-Flash	72
4.4.15	LVDS Configuration	73
4.5	Hardware Monitor menu	75
4.6	Security menu	76
4.7	Boot menu	80
4.8	Exit menu	83
4.9	Updating your BIOS	85
4.9.1	ASUS CrashFree BIOS utility	85
4.9.2	ASUS EZ-Flash Utility	86

Appendix

Safety information	90
Setting up your system	90
Safety precautions	90
Care during use	91
Regulatory notices	92
Service and Support	96

About this manual

This manual provides information about the hardware and software features of your Single Board Computer, organized through the following chapters:

Chapter 1: Specifications Summary

This chapter details the hardware and software features of your Single Board Computer.

Chapter 2: Product Introduction

This chapter describes the features of the motherboard. It includes description of the connectors, and I/O ports on the motherboard.

Chapter 3: Upgrading your Single Board Computer

This chapter provides you with information on how to upgrade the memory modules, wireless modules, and hard disk drive / solid state drive of your Single Board Computer.

Chapter 4: BIOS Setup

This chapter tells how to change system settings through the BIOS Setup menus. Detailed descriptions of the BIOS parameters are also provided.

Appendix

This section includes notices and safety statements for your Single Board Computer.

Conventions used in this manual

To highlight key information in this manual, some text are presented as follows:


IMPORTANT! This message contains vital information that must be followed to complete a task.

NOTE: This message contains additional information and tips that can help complete tasks.


WARNING! This message contains important information that must be followed to keep you safe while performing certain tasks and prevent damage to your Single Board Computer's data and components.

Package contents

Your Single Board Computer package contains the following items:



X621ES-IM-AA / X641ES-IM-AA / X642ES-IM-AA



SATA and power cable

NOTE:

- Some bundled accessories may vary depending on model. For details on these accessories, refer to their respective user manuals.
 - The device illustration is for reference only. Actual product specifications may vary with models.
 - If the device or its components fail or malfunction during normal and proper use within the warranty period, bring the warranty card to the ASUS Service Center for replacement of the defective components.
-

1

Specifications Summary

Specifications Summary


Product Name	CPU Intel® Atom®	Processor Base Frequency	Memory
X621ES-IM-AA	x6211E	1.3 GHz Dual-core	DDR4 Max. 32 GB
X641ES-IM-AA	x6413E	1.5 GHz Quad-core	
X642ES-IM-AA	x6425E	2.0 GHz Quad-core	

Form factor		3.5", 146 x 105 mm
Display	HDMI	1 x HDMI 2.0 up to 4096 x 2160 @ 60 Hz
	DisplayPort	1 x DisplayPort supports DP++1.2 up to 4096 x 2160 @ 60 Hz
	LVDS	1 x LVDS supports 1920 x 1080 @ 60 Hz (co-lay with eDP)
	Multi Display	HDMI+DP+LVDS HDMI+DP+eDP Supports up to 3 displays simultaneous under OS
Expansion slot	M.2	1 x M.2 2230 E-key slot (USB 2.0, PCIe) supports Wi-Fi/BT modules 1 x M.2 2280 M-key slot (SATA, PCIe x2) supports M.2 SSD/PCIe modules 1 x M.2 3042/3052 B-key slot (USB 2.0) supports 4G LTE modules
Storage	SATA	1 x SATA Gen 3.0, up to 6 Gb/s
Audio	Codec	Realtek® ALC897
Ethernet		1 x Intel® I210-IT, RJ-45 LAN port supports 10/100/1000 Mbps and WOL/PXE
Rear I/O		1 x HDMI port 1 x DisplayPort 4 x USB 10G ports (Type A) 2 x RJ-45 LAN ports 2 x LED indicators

(continued on the next page)

Internal connectors	6 x Serial connectors support 2 x RS-232/422/485 ports and 4 x RS-232 1 x USB 2.0 connector supports additional 2 USB 2.0 ports) 1 x Chassis Fan connector 1 x Chassis Intruder connector 1 x Front Panel Audio (AAFP) connector 1 x System Panel connector 1 x SATA Power connector 1 x COM Debug connector 1 x SMBus connector 1 x I2C connector 1 x GPIO connector (8-bit) 1 x AMP connector 1 x Power connector 1 x Clear CMOS jumper 1 x AT/ATX Select jumper 1 x Display Panel VCC Power Selection jumper	
Watchdog Timer	H/W: No S/W: Yes	
Security	TPM 2.0	
Power Supply	DC input 9-36 V	
Operating System	Windows® 10 (64bit) Windows® 10 IoT Enterprise Ubuntu	
Environment	Operating Temperature:	-40°C ~ 85°C
	Non-operating Temperature:	-40°C ~ 85°C
	Operating Humidity:	40°C @ 95%

NOTE: Specifications are subject to change without notice.



2

Product Introduction

2.1 Before you proceed

Take note of the following precautions before you install motherboard components or change any motherboard settings.


NOTE: The diagrams in this chapter are for reference only. The motherboard layout may vary with models.

IMPORTANT! Components shown in this section may require additional purchase. Refer to **Package contents** section for more information about the contents of your Single Board Computer package.

WARNING!

- Unplug the power cord from the wall socket before touching any component.
 - Before handling components, use a grounded wrist strap or touch a safely grounded object or a metal object, such as the power supply case, to avoid damaging them due to static electricity.
 - Hold components by the edges to avoid touching the ICs on them.
 - Whenever you uninstall any component, place it on a grounded antistatic pad or in the bag that came with the component.
 - Before you install or remove any component, ensure that the ATX power supply is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, or components.
-

2.2 Motherboard layout





Jumpers		Page
1.	Clear RTC RAM jumper	18
2.	Display Panel VCC Power Selection jumper	19
3.	COM +5V/+12V Selection jumper	19
4.	AT/ATX Mode Configuration jumper	20

Connectors/slots		Page
1.	M.2 (E-key) Wi-Fi slot	21
2.	M.2 (B-key) slot	21
3.	Battery connector	22
4.	LVDS connector	22
5.	M.2 (M-key) slot	23
6.	Backlight Inverter Power connector	23
7.	Serial Port connector	24
8.	Chassis intrusion connector	25
9.	DIMM slot	17
10.	COM Debug connector	25
11.	Fan connector	26
12.	Nano SIM Card slot	26
13.	USB 2.0 connector	27
14.	SATA Power connector	28
15.	DC-in Power connector	29
16.	SATA connector	28
17.	I2C connector	29
18.	SMBus connector	30
19.	SPI TPM connector	30
20.	GPIO connector	31
21.	Power Button connector	31
22.	Stereo Out connector	32
23.	System Panel connector	33
24.	Line Out / Mic connector	34

2.3 System memory

The motherboard comes with one (1) Small Outline Dual Inline Memory Module (SODIMM) slot designed for DDR4 (Double Data Rate 4) memory modules.

WARNING! Make sure to unplug the power supply before adding or removing DIMMs or other system components. Failure to do so may cause severe damage to both the motherboard and the components.




SODIMM_A1

2.4 Onboard jumpers & switches

1. Clear RTC RAM jumper

The Clear RTC RAM jumper allows you to clear the Real Time Clock (RTC) RAM in the CMOS, which contains the date, time, system passwords, and system setup parameters.




To erase the RTC RAM:

1. Turn OFF the computer and unplug the power cord.
2. Short-circuit pin 1-2 with a metal object or jumper cap for about 5-10 seconds.
3. Plug the power cord and turn ON the computer.
4. Hold down the key during the boot process and enter BIOS setup to re-enter data.


NOTE: If the steps above do not help, remove the onboard button cell battery and move the jumper again to clear the CMOS RTC RAM data. After clearing the CMOS, reinstall the button cell battery.

2. Display Panel VCC Power Selection jumper (on selected models)

The Display Panel VCC Power Selection jumper allows you to select the voltage for the LVDS panel.




VCC_PWR_SEL




3. COM +5V/+12V Selection jumper

The COM +5V/+12V Selection jumper allows you to select the voltage for the COM1 and COM2 ports.




A COM2_SEL

B COM1_SEL



4. AT/ATX Mode Configuration jumper

The AT/ATX Mode Configuration jumper allows you to switch between AT and ATX modes. The default setting for this jumper is set to ATX mode with a jumper cap attached. To switch to AT mode, remove the jumper cap.




AT_ATX_SEL



2.5 Internal connectors

1. M.2 (E-key) Wi-Fi slot


The M.2 Wi-Fi slot allows you to install an M.2 Wi-Fi module (E-key, type 2230).



NOTE: The M.2 Wi-Fi module is purchased separately.

2. M.2 (B-key) slot


The M.2 (B-key) slot allows you to install a B-key (USB2.0) type 3042/3052 M.2 device, such as a 4G LTE or 5G NR module.



NOTE: The M.2 4G LTE or 5G NR module is purchased separately.

3. Battery connector

The Battery connector allows you to connect a lithium CMOS battery.




BATT_CON




4. LVDS connector

The LVDS connector allows you to connect an LCD monitor that supports a Low-voltage Differential Signaling (LVDS) interface.



LVDS_EDP




Connector type

WtoB 2x20p, 1.25mm pitch

5. M.2 (M-key) slot

The M.2 slot allows you to install 2242/2280 M.2 devices, such as 2242/2280 M.2 SSD modules.




NOTE: The M.2 SSD module is purchased separately.

6. Backlight Inverter Power connector

The Backlight Inverter Power connector allows you to power the backlight inverter on a display panel via a backlight inverter module.

IMPORTANT! The Backlight Inverter Power connector supports a maximum current of 3A.




Connector type

Header 1x5p, K6, 2.0mm pitch

7. Serial Port connector

The Serial (COM) Port connector allows you to connect a serial port module. Connect the serial port module cable to this connector, then install the module to a slot opening on the system chassis.



Connector type


BOX header 2x10p, K10, 2.0mm pitch

NOTE:

- The serial port module is purchased separately.
- **COM1** and **COM2** support RS-232/422/485.

8. Chassis Intrusion connector

The Chassis Intrusion connector allows you to connect an intrusion sensor or microswitch for the chassis intrusion detection feature. When you remove any chassis component, the sensor or microswitch triggers and sends a high level signal and records a chassis intrusion event.




INTRUDER




NOTE: By default, a jumper cap that disables the intrusion detection feature is installed on the connector to prevent accidental triggers.

9. COM Debug connector

The COM Debug connector allows you to connect a COM debug card.



COM_DBG




Connector type


Header 2x3p, 2.54mm pitch

10. Fan connector

The fan connector allows you to connect a fan to actively cool the system.



CHA_FAN




Connector type

WtoB 1x4p, 1.25mm pitch

11. Nano SIM Card slot

The Nano SIM Card slot allows you to install a Nano SIM card.





SIM



NOTE: The Nano SIM card is purchased separately.

12. USB 2.0 connector

The USB 2.0 connector allows you to connect a USB module for additional USB 2.0 ports. The USB 2.0 connector provides data transfer speeds of up to 480 MB/s connection speed.



Connector type


BOX header 2x5p, K9, 2.0mm pitch

WARNING! DO NOT connect a 1394 cable to the USB connectors. Doing so will damage the motherboard!

NOTE: The USB 2.0 module is purchased separately.

13. SATA 6Gb/s & SATA Power connector

The SATA 6Gb/s and SATA Power connectors allow you to connect SATA devices such as optical disc drives and hard disk drives via a SATA cable and power cable.




Connector type

Wafer HD 4P, 2.0mm pitch & Wafer HD 7p, 1.27mm pitch

NOTE: Ensure to use the bundled cable when connecting a storage device to this connector.

14. DC-in 4-Pin Power connector

The DC-in 4-pin Power connector is for DC power input. Using a compatible power cable and power board, you may connect a suitable power supply with DC-in jacks.




Connector type

POWER CON 4P R/A

15. I2C connector

The I2C (Inter-Integrated Circuit) connector allows you to connect an I2C-compatible IoT security module.




Connector type

Header 1x3p, K6, 2.0mm pitch

16. SMBus connector

The System Management Bus (SMBus) connector allows you to connect SMBus devices. This connector is generally used for communication with system and power management-related tasks.




Connector type

Header 1x4p, 2.0mm pitch

17. SPI TPM connector

The SPI TPM connector supports a Trusted Platform Module (TPM) system, which can securely store keys, digital certificates, passwords, and data. A TPM system also helps enhance network security, protects digital identities, and ensures platform integrity.





Connector type

Header 2x7p, K14, 2.0mm pitch

18. GPIO connector

The GPIO connector allows you to connect a general purpose input/output module to customize digital signal input/output.




Connector type


BOX header 2x5p, K9, 2.0mm pitch

19. Power Button connector

The Power Button connector allows you to connect an external power button.




PWRBTN_EXT




20. Stereo Out connector

The Stereo Out connector allows you to connect a stereo speaker. This connector supports 2 W at 4 Ω stereo speakers.




21. Front Panel connector

The Front Panel connector supports several chassis-mounted functions.



F_PANEL



Connector type

BOX header 2x5p 2.0mm pitch

- **System Power LED connector (PLED)**

The 2-pin connector allow you to connect the System Power LED. The System Power LED lights up when the system is connected to a power source, or when you turn on the system power, and blinks when the system is in sleep mode.

- **Storage Device Activity LED connector (HDLED)**

The 2-pin connector allows you to connect the Storage Device Activity LED. The Storage Device Activity LED lights up or blinks when data is read from or written to the storage device or storage device add-on card.

- **Power Button/Soft-off Button connector (PWRBTN)**


The 3-1 pin connector allows you to connect the system power button. Press the power button to power up the system, or put the system into sleep or soft-off mode (depending on the operating system settings).

- **Reset button connector (O_RSTCON)**


The 2-pin connector allows you to connect the chassis-mounted reset button. Press the reset button to reboot the system.

22. Front Panel Audio (Line Out / Mic) connector

The Front Panel Audio connector is for a line out /microphone module that supports HD Audio. Connect one end of the line out / mic module cable to this connector.



AAFP



Connector type

BOX header 2x5p, K8, 2.0mm pitch

NOTE: We recommend that you connect a high-definition line out / mic module to this connector to avail of the motherboard's high-definition audio capability.

2.6 I/O connectors

Front panel



Front panel connectors

- | | |
|----|-------------------------|
| 1. | HDMI ports |
| 2. | DisplayPort |
| 3. | USB 10 G ports (Type-A) |
| 4. | LAN (RJ-45) 1 Gbe ports |

3

Upgrading your Single Board Computer

IMPORTANT!


- Ensure that your hands are dry before proceeding with the rest of the installation process. Before installing any of the features in this guide, use a grounded wrist strap or touch a safely grounded object or metal object to avoid damaging them due to static electricity.
 - Turn off the power of your Single Board Computer, and allow it to cool for at least 10 minutes before performing any installation/uninstallation process.
-

NOTE: The illustrations in this section are for reference only. The slots may vary depending on model.

3.1 Installing memory modules


Your Single Board Computer comes with an SO-DIMM slot that allows you to install DDR4 SO-DIMMs.

Align and insert the memory module into the slot (A) and press it down (B) until it is securely seated in place.





3.2 Installing a 2.5-inch storage device

1. Connect the storage device cable to the storage device.




2. Connect the storage device cable to the **SATA6G** and **SATA_PWR** connectors on the motherboard.




3.3 Installing an M.2 SSD

1. (Optional) Replace the standoff if it has been removed, or move and install it based on the length of your M.2 SSD.
2. Align and insert the M.2 SSD into its slot inside the Single Board Computer.
3. Gently push down the M.2 SSD on top of the standoff, and then fasten it using a screw.



3.4 Installing a nano SIM card

1. (Optional) Remove the M.2 module from the M.2 B-key slot, if one is installed, by first removing the screw securing the module, and then removing the module.
2. Push the nano SIM cover in the direction away from the SO-DIMM slots.
3. Lift the nano SIM cover.
4. Place the nano SIM into the nano SIM slot.
5. Close the nano SIM cover.
6. Push the nano SIM cover towards the SO-DIMM slots to secure the nano SIM card.





3.5 Installing a wireless card

1. Remove the screw from the M.2 standoff.
 2. Align and insert the wireless card into its slot on the motherboard. Gently push down the wireless card on top of the standoff, and then fasten it using the previously removed screw.
 3. (Optional) Connect the antennas to your wireless card.
-

NOTE:

- Connecting antennas to your wireless card may strengthen the wireless signal.
 - A soft clicking sound indicates that the antenna has been securely attached on the wireless card.
 - The antennas are purchased separately.
-



3.6 Installing an M.2 B-key module

Your Embedded Computer comes with an M.2 (B-key) slot that allows you to install a B-key (USB2.0) type 3042/3052 M.2 device, such as a 4G LTE or 5G NR module.

To install a 4G LTE module:

1. Remove the screw from the M.2 standoff.
2. Align and insert the module into the slot.
3. Press down, and then secure it in place using the screw previously removed.
4. (Optional) Connect the RF cables from the antennas to your module. Make sure that the correct cable is attached to each of the connectors by following chart on the next page.

NOTE:


- To enable the hot-plug function of your 4G LTE module, click the **weston-terminal** icon in the upper left corner of your screen, and type the first command below when prompted:

```
mm_cli sim-detect 1           (enable hot-plug function)
mm_cli sim-detect 0           (disable hot-plug function)
mm_cli sim-detect             (display current setting)
```

- Refer to **Installing antennas** for more information on installing the antennas.
 - Connecting antennas to your module may strengthen the signal.
 - A soft clicking sound indicates that the antenna has been securely attached on the module.
-


3.7 Installing a heatsink

1. Place the heatsink with its fins faced down on a flat surface.
2. Remove the plastic film on the thermal pads.
3. Orient the motherboard so that the CPU on its backside are in direct contact with the copper pad on the heatsink, and the five (5) screw holes on the motherboard are aligned to the five (5) standoffs on the heatsink as shown below.
4. Secure the motherboard to the heatsink using the five (5) spring screws bundled with the heatsink in the sequence shown below.





3.8 Installing a heat spreader

1. Place the heat spreader with its copper pad and thermal interface material facing up on a flat surface.
2. Remove the plastic protective film from the copper pad and thermal interface material on the heat spreader, if there is one.



3. Orient the motherboard so that the CPU, chipset, and EMMC on its backside are in direct contact with the copper pad on the heat spreader, and the five (5) screw holes on the motherboard are aligned to the five (5) standoffs on the heat spreader.

4. Secure the motherboard to the heat spreader using the five (5) M2.5 spring screws bundled with the heat spreader in the sequence shown below.



4

BIOS Setup

4.1 Getting to know your BIOS

The BIOS (Basic Input and Output System) stores system hardware settings such as Storage Device Configuration, Advanced Power Management, and Boot Device Configuration that are needed for system startup. Under normal circumstances, the default BIOS settings apply to most conditions to ensure optimal performance. DO NOT change the default BIOS settings except in the following circumstances:

- An error message appears on the screen during the system bootup and requests you to run the BIOS setup.
- You have installed a new system component that requires further BIOS settings or update.

WARNING! Inappropriate BIOS settings may result to instability or boot failure. We strongly recommend that you change the BIOS settings only with the help of a trained service personnel.

4.2 BIOS setup program

Use the BIOS Setup program to update the BIOS or configure its parameters. The BIOS screens include navigation keys and brief online help to guide you in using the BIOS Setup program.

Entering BIOS Setup at startup

To enter BIOS Setup at startup:

- Press <Delete> or <ESC> during the Power-On Self Test (POST). If you do not press <Delete> or <ESC>, POST continues with its routines.


Entering BIOS Setup after POST

To enter BIOS Setup after POST:

- Press <Ctrl>+<Alt>+<Delete> simultaneously.
- Press the power switch to turn the system off then back on. Do this option only if you failed to enter BIOS Setup using the first option.

BIOS menu screen

This section provides a brief introduction of the BIOS Interface of your Single Board Computer.



Menu bar

The menu bar on top of the screen has the following main items:

Main	For changing the basic system configuration
Advanced	For changing the advanced system settings
Hardware Monitor	For viewing system temperature/power status and changing the fan mode
Security	For changing the security settings
Boot	For changing the system boot configuration
Exit	For selecting the save and exit options or loading default settings

4.3 Main Menu

When you enter the BIOS Setup program, the Main menu screen appears. The Main menu provides you an overview of the basic system information, and allows you to set the system date and time. Scroll down to display the other BIOS items.



4.3.1 System Date [Day xx/xx/xxxx]

Allows you to set the system date.


4.3.2 System Time [xx:xx:xx]

Allows you to set the system time.

4.4 Advanced menu


The Advanced menu items allow you to change the settings for the CPU and other system devices.

WARNING! Be cautious when changing the settings of the Advanced menu items. Incorrect field values can cause the system to malfunction.



4.4.1 PCH-FW Configuration

The items in this menu allow you to configure Management Engine Technology Parameters.



TPM Device Selection

This item allows you to select the TPM device.

[dTPM] Discrete TPM

[PTT] Intel Platform Trust Technology firmware TPM

NOTE:

- When **[dTPM]** is selected, PTT (firmware TPM) will be disabled, and the TPM device connected to the SPI TPM connector on the motherboard will be enabled. If no TPM device is connected, the TPM feature will be disabled.
- When **[PTT]** is selected, PTT (firmware TPM) is enabled.

WARNING! When **[dTPM]** is selected, PTT (firmware TPM) will be disabled and all data saved on it will be lost.

4.4.2 Trusted Computing

Aptio Setup - AMI		
Advanced		
Configuration		
Security Device Support	[Enable]	Enables or Disables BIOS support for security device.
NO Security Device Found		O.S. will not show Security

NOTE: Changes here do not take effect until computer is restarted.


Security Device Support

Allows you to enable or disable the BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

Configuration options: [Disable] [Enable]

4.4.3 CPU Configuration

The items in this menu show the CPU-related information that the BIOS automatically detects. Scroll down to display other BIOS items.



Intel (VMX) Virtualization Technology

When set to **[Enabled]**, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

Configuration options: [Disabled] [Enabled]

VT-d

Allows you to enable or disable VT-d capability.

Configuration options: [Disabled] [Enabled]

CPU – Power Management Control

Intel(R) SpeedStep(tm)

Allows more than two frequency to be supported.

Configuration options: [Disabled] [Enabled]

Intel(R) Speed Shift Technology

Allows you to enable or disable Intel(R) Speed Shift Technology support. When enabled, CPPC v2 interface allows hardware controlled P-states.

Configuration options: [Disabled] [Enabled]

Turbo Mode

Allows you to enable or disable processor Turbo Mode (requires Intel Speed Step or Intel Speed Shift to be available when enabled).

Configuration options: [Disabled] [Enabled]

C states

Allows you to enable or disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.

Configuration options: [Disabled] [Enabled]

NOTE: The following item appears only when **C states** is set to **[Enabled]**.

Enhanced C-States

Allows you to enable or disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State.

Configuration options: [Disabled] [Enabled]

Power Limit 1 Override

Allows you to enable or disable Power Limit 1 override. If this option is disabled, BIOS will program the default values for Power Limit 1 and Power Limit 1 Time Window

Configuration options: [Disabled] [Enabled]

Power Limit 2 Override

Allows you to enable or disable Power Limit 2 override. If this option is disabled, BIOS will program the default values for Power Limit 2.

Configuration options: [Disabled] [Enabled]


NOTE: The following item appears only when **Power Limit 2 Override** is set to **[Enabled]**.

Power Limit 2

Allows you to configure Power Limit 2 value in milliwatts (e.g., enter 12500 for 12.5 W).

4.4.4 Graphics Configuration

The items in this menu allow you to configure settings related to graphics.




RC6(Render Standby)

Allows you to enable or disable render standby support.

Configuration options: [Disabled] [Enabled]

4.4.5 Super IO Configuration

The items in this menu allow you to configure system super IO chip parameters.



NCT6126D Super IO Configuration

Serial Port 1-2 Configuration

Allows you to set the parameters of Serial Port 1-2.

Serial Port

Allows you to enable or disable Serial Port.

Configuration options: [Disabled] [Enabled]

NOTE: The following items appear only when **Serial Port** is set to **[Enabled]**.

COM1-2 Control

Configuration options: [RS232] [RS422] [RS485]

Serial Port 3-6 Configuration

Allows you to set the parameters of Serial Port 3-6.


Serial Port

Allows you to enable or disable Serial Port.

Configuration options: [Disabled] [Enabled]

4.4.6 Serial Console Redirection

The items in this menu allow you to configure serial console redirection parameters.



COM1-6

Console Redirection

Allows you to enable or disable the console redirection feature.

Configuration options: [Disabled] [Enabled]

NOTE: The following item appears only when **Console Redirection** is set to **[Enabled]**.

Console Redirection Settings

This item becomes configurable only when you enable the **Console Redirection** item. The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Terminal Type

Allows you to set the terminal type.

[VT100] ASCII char set.

[VT100+] Extends VT100 to support color, function keys, etc.

[VT-UTF8] Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.

[ANSI] Extended ASCII char set.

Bits per second

Selects serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

Configuration options: [9600] [19200] [38400] [57600] [115200]

Data Bits

Configuration options: [7] [8]

Parity

A parity bit can be sent with the data bits to detect some transmission errors. **[Mark]** and **[Space]** parity do not allow for error detection.

[None] None.

[Even] parity bit is 0 if the num of 1's in the data bits is even.

[Odd] parity bit is 0 if num of 1's in the data bits is odd.

[Mark] parity bit is always 1.

[Space] parity bit is always 0.

Stop Bits

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning.) The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

Configuration options: [1] [2]

Flow Control

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

Configuration options: [None] [Hardware RTS/CTS]

VT-UTF8 Combo Key Support

Allows you to enable the VT-UTF8 Combo Key Support for ANSI/VT100 terminals.

Configuration options: [Disabled] [Enabled]

Recorder Mode

With this mode enabled only text will be sent. This is to capture Terminal data.

Configuration options: [Disabled] [Enabled]

Resolution 100x31

Allows you to enable or disable extended terminal resolution.

Configuration options: [Disabled] [Enabled]

Putty KeyPad


Allows you to select the FunctionKey and Keypad on Putty.

Configuration options: [VT100] [LINUX] [XTERM6] [SCO] [ESCN] [VT400]

4.4.7 SATA Configuration

The items in this menu allow you to configure SATA device options.

While entering Setup, the BIOS automatically detects the presence of SATA devices. The SATA Port items show **[Empty]** if no SATA device is installed to the corresponding SATA port.



SATA Controller(s)

Allows you to enable or disable the SATA Controller.

Configuration options: [Enabled] [Disabled]

NOTE: The following items appear only when **SATA Controller(s)** is set to **[Enabled]**.

SATA Mode Selection

Allows you to determine how SATA controller(s) operate.

Configuration options: [AHCI]

M.2 B-Key(SATA)

Allows you to enable or disable the SATA port.

Configuration options: [Disabled] [Enabled]


SATA6G

Allows you to enable or disable the SATA port.

Configuration options: [Disabled] [Enabled]

4.4.8 Network Stack Configuration

Allows you to configure network stack settings.



Network Stack

Allows you to enable or disable UEFI Network Stack.

Configuration options: [Disabled] [Enabled]

NOTE: The following items appear only when **Network Stack** is set to **[Enabled]**.

IPv4 PXE Support

Enables or disables the IPv4 PXE Boot Support. If disabled, IPv4 PXE boot option will not be created.


Configuration options: [Disabled] [Enabled]

IPv6 PXE Support

Enables or disables the IPv6 PXE Boot Support. If disabled, IPv6 PXE boot option will not be created.

Configuration options: [Disabled] [Enabled]

4.4.9 USB Configuration



NOTE: The **USB Devices** item shows the auto-detected values. If no USB device is detected, the item shows **None**.

XHCI Hand-off

Allows you to enable or disable workaround for Oses without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

Configuration options: [Disabled] [Enabled]

NOTE: This item is set to **[Disabled]** by default for the EHCI (enhanced host controller interface) support by XHCI drivers in operating systems.

USB Mass Storage Driver Support

Allows you to enable or disable the USB Mass Storage driver support.

Configuration options: [Disabled] [Enabled]

USB32G2_1-4

Allows you to enable or disable each USB port. When set to [Disabled], any USB devices plugged into the connector will not be detected by the BIOS or OS.

Configuration options: [Disabled] [Enabled]


USB1-2

Allows you to enable or disable each USB port. When set to [Disabled], any USB devices plugged into the connector will not be detected by the BIOS or OS.


Configuration options: [Disabled] [Enabled]

4.4.10 NVMe Configuration

This menu displays the controller and drive information for NVMe devices connected and allows you to configure NVMe device options.



4.4.11 Onboard Devices Configuration



HD Audio

Allows you to unconditionally enable or disable the HD audio device.

Configuration options: [Disabled] [Enabled]

Intel I210-IT LAN 1 Controller

Allows you to enable or disable the LAN 1 controller.

Configuration options: [Disabled] [Enabled]

Intel I210-IT LAN 2 Controller

Allows you to enable or disable the LAN 2 controller.

Configuration options: [Disabled] [Enabled]

M.2 M-Key(PCIe)

Allows you to enable or disable the M.2 M-Key (PCIe) controller.

Configuration options: [Disabled] [Enabled]

M.2 B-Key(USB)

Allows you to enable or disable the M.2 B-Key (USB) controller.

Configuration options: [Disabled] [Enabled]

I2C Controller

Allows you to enable or disable I2C controller support.

Configuration options: [Disabled] [Enabled]

In-Band ECC

Allows you to enable or disable In-Band ECC.

Configuration options: [Enabled] [Disabled]

M.2(WiFi)

PCIe Port (WiFi)

Allows you to enable or disable the M.2 WiFi (PCIe port) controller.

Configuration options: [Disabled] [Enabled]

USB Port (BT)

Allows you to enable or disable the M.2 BT (USB port) controller.

Configuration options: [Disabled] [Enabled]

4.4.12 APM Configuration

Allows you to configure the Advance Power Management (APM) settings.

Advanced		ApMio Setup - AMI
APM Configuration		Allow BIOS to switch off some power
ErP Ready	[Disabled]	at S4/S5 to get the system ready for ErP requirement. When set to Enabled, all other PME options will be switched
Restore AC Power Loss	[S5 State]	
Power On By PCIE	[Disabled]	
Power On By Ring	[Disabled]	
Power On By RTC	[Disabled]	

ErP Ready

Allows the BIOS to switch off some power at S4/S5 to get the system ready for ErP requirement.

Configuration options: [Disabled] [Enabled]

NOTE: When set to **[Enabled]**, all other PME options will be switched off.

Restore AC Power Loss

[S5] The system goes into OFF state after an AC power loss.

[S0] The system goes into ON state after an AC power loss.

Power On By PCIE

Allows you to enable or disable the wake-on-LAN function for the onboard LAN controller or other installed PCIe/PCI LAN cards.

Configuration options: [Disabled] [Enabled]

Power On By Ring

Allows the computer to be powered on or awakened from a low-power state in response to ring events, such as network activity.

Configuration options: [Disabled] [Enabled]


Power On By RTC

Allows you to disable the real-time clock (RTC) or enable it to schedule a wake event.

Configuration options: [Disabled] [Single event] [Daily event] [Weekly event] [Monthly event]

4.4.13 Watchdog Timer

The items in this menu allow you to configure settings related to Watchdog Timer.



Watchdog Support

Allows you to enable or disable Watchdog Support.

Configuration options: [Disabled] [Enabled]

NOTE: The following items appear only when **Watchdog Support** is set to **[Enabled]**.

Watchdog Count Mode


Allows you to select the Watchdog Timer - count mode.

Configuration options: [Second Mode] [Minute Mode]

Watchdog Timer

Allows you to input the Watchdog time-out interval.

4.4.14 EZ-Flash




Enter Ez-Flash mode

Allows you to enter Ez-Flash mode to run the ASUS Ez-Flash BIOS ROM utility.

WARNING! Make sure to back up your Bitlocker recovery key and suspend Bitlocker encryption in the operating system before updating your BIOS.

4.4.15 LVDS Configuration



IGD Flat Panel

Allows you to enable or disable IGD video output to onboard LVDS.

Configuration options: [Auto] [Enabled] [Disabled]

NOTE: The following items appear only when **IGD Flat Panel** is set to **[Auto]** or **[Enabled]**

All-in-One Chassis

Allows you to select All-in-One (AiO) chassis (if applicable) for simplified AiO configuration.

Configuration options: [None] [1920*1080 LVDS1] [1920*1080 LVDS2]
[1920*1080 LVDS3] [1600*900 LVDS4]

IMPORTANT! Be cautious when selecting AiO chassis. Incorrect selection of AiO chassis can cause incorrect operation or potential damage to AiO chassis hardware.

NOTE: The following items appear only when you set **All-in-One Chassis** to **[None]**.

EDID Data Source

Configuration options: [Pre-defined] [Flat Panel Display]

NOTE: The following item appears when you set **EDID Data Source** to **[Pre-defined]**.

Pre-Defined LVDS Panel Type

Allows you to select LVDS panel used by Internal Graphics Device.

Configuration options: [VBIOS Default] [640x480] [800x600] [1024x768] [1280x1024] [1400x1050(RB) LVDS1] [1400x1050 LVDS2] [1600x1200 LVDS] [1366x768 LVDS] [1680x1050] [1920x1200] [1440x900 LVDS] [1600x900 LVDS] [1024x768 LVDS2] [1280x800] [1920x1080 LVDS] [2048x1536 LVDS]

Inverter Polarity

Allows you to set the inverter board polarity.

Configuration options: [Inverted] [Normal]

NOTE:

- Normal: PWM = 0% (Dim)
Inverted: PWM = 0% (Bright)
 - Consult inverter board specifications for proper value.
-

Channel Select


Configuration options: [Dual Channel] [Single Channel]

Mode Select

Configuration options: [JEIDA] [VESA 6bit] [VESA 8bit] [VESA 10bit]

4.5 Hardware Monitor menu

The Hardware Monitor menu displays the system temperature/power status, and allows you to change the fan mode.




Smart Fan Mode

Allows you to select a smart fan mode.

Configuration options: [Disabled] [Normal] [Manual Mode]

4.6 Security menu

This menu allows a new password to be created or a current password to be changed. The menu also enables or disables the Secure Boot state and lets the user configure the System Mode state.



Administrator Password

To set an administrator password:

1. Select the Administrator Password item and press <Enter>.
2. From the Create New Password box, key in a password, then press <Enter>.
3. Confirm the password when prompted.

To change an administrator password:

1. Select the Administrator Password item and press <Enter>.
2. From the Enter Current Password box, key in the current password, then press <Enter>.

3. From the Create New Password box, key in a new password, then press <Enter>.
4. Confirm the password when prompted. **NOTE:** To clear the administrator password, follow the same steps as in changing an administrator password, but press <Enter> when prompted to create/confirm the password.

User Password

To set a user password:

1. Select the User Password item and press <Enter>.
2. From the Create New Password box, key in a password, then press <Enter>.
3. Confirm the password when prompted.

To change a user password:

1. Select the User Password item and press <Enter>.
2. From the Enter Current Password box, key in the current password, then press <Enter>.
3. From the Create New Password box, key in a new password, then press <Enter>.
4. Confirm the password when prompted.

To clear a user password:

1. Follow the same steps as in changing a user password, but press <Enter> when prompted to create a new password.
2. Select Yes from the Warning message window, then press <Enter>.

Secure Boot

Secure Boot can be enabled if the system is running in User mode with enrolled platform Key (EPK) or if the CSM function is disabled.

Configuration options: [Disabled] [Enabled]

Secure Boot Mode

In Custom Mode, the secure boot policy variables can be configured by a physically present user without full authentication.

Configuration options: [Standard] [Custom]

Key Management

The Key Management item allows you to modify Secure Boot variables and set Key Management page.

Platform Key (PK)

Configuration options: [Details] [Export] [Update] [Delete]

Key Exchange Keys / Authorized Signatures / Forbidden Signatures

Configuration options: [Details] [Export] [Update] [Append] [Delete]

HDD Security Configuration

The HDD Security Configuration item allows you to set up passwords to protect your HDD.

NOTE: This item is only available when you have a SATA HDD connected.

To set a password for your HDD:

1. Select the HDD Security Configuration item and press <Enter>.
2. Select the Set Master Password item and press <Enter>.
3. From the Create New Password box, key in a password, then press <Enter>.
4. Confirm the password when prompted.
5. Select the User Password item and press <Enter>.
6. From the Create New Password box, key in a password, then press <Enter>.
7. Confirm the password when prompted.


To change the password for your HDD:

1. Select the HDD Security Configuration item and press <Enter>.
2. Select the Set User Password item and press <Enter>.
3. From the Enter Current Password box, key in a password, then press <Enter>.
4. From the Create New Password box, key in a password, then press <Enter>.
5. Confirm the password when prompted.

NOTE: To clear the user password, follow the same steps as in changing a user password, but press <Enter> when prompted to create/confirm the password.

4.7 Boot menu

The Boot menu items allow you to change the system boot options.



Boot Configuration

CHASSIS INTRUDE

Allows you to enable or disable chassis intrusion detection function.
Configuration options: [Disabled] [Enabled]

Setup Prompt Timeout

Allows you to set the number of seconds that the firmware waits before initiating the original default boot selection. 65535(0xFFFF) means indefinite waiting. Use <+> or <-> to adjust the value.

Post Time Delay

Allows you to select a desired additional POST waiting time to easily enter the BIOS Setup. You can only execute the POST time delay during normal boot. The values range from 0 to 10 seconds.

NOTE: This feature only works when set under normal boot.

Bootup NumLock State

Allows you to select the power-on state for the NumLock.
Configuration options: [On] [Off]

Quiet Boot

Allows you to enable or disable the Quiet Boot option.
Configuration options: [Disabled] [Enabled]

Fast Boot

[Disabled] Allows your system to go back to its normal boot speed.
[Enabled] Allows your system to accelerate the boot speed.

FIXED BOOT ORDER Priorities

These items specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system.

NOTE:

- To access Windows® OS in Safe Mode, press <F8> after POST (Windows® 8 not supported).
 - To select the boot device during system startup, press <F8> when the ASUS Logo appears.
-

UEFI Hard Disk Drive BBS Priorities

Allows you to specify the Boot Device Priority sequence from available UEFI Hard Disk Drives.

Boot Option #1

Allows you to set the system boot order.

Configuration options: [Windows Boot Manager] [Disable]

UEFI USB Drive BBS Priorities

Allows you to specify the Boot Device Priority sequence from available UEFI USB Drives.

Boot Option #1

Allows you to set the system boot order.

Configuration options: [UEFI] [Disable]

4.8 Exit menu

The Save & Exit menu items allow you to save or discard your changes to the BIOS items.



NOTE: Pressing <ESC> does not immediately exit this menu. Select one of the options from this menu or <F10> from the legend bar to exit.

Save Changes and Exit

Exit system setup after saving changes.

Discard Changes and Exit

Exit system setup without saving changes.

Save Changes and Reset

Exit system setup after saving changes.

Discard Changes and Reset

Reset the system without saving any changes.

Save Option

Save Changes

Save changes done so far to any of the setup options.

Discard Changes

Discard changes done so far to any of the setup options.

Restore Defaults

Restore/load default values for all the setup options.

Save as User Defaults

Save the changes done so far as User Defaults.

Restore User Defaults

Restore/load default values for all the setup options.

Boot Override

Windows Boot Manage

4.9 Updating your BIOS

The following utilities allow you to manage and update the motherboard Basic Input/Output System (BIOS) setup:

1. **ASUS CrashFree BIOS**

To recover the BIOS using a bootable USB flash disk drive when the BIOS file fails or is corrupt.

2. **ASUS EzFlash**

Updates the BIOS using a USB flash disk.

Refer to the corresponding sections for details on these utilities.

4.9.1 **ASUS CrashFree BIOS utility**

The ASUS CrashFree BIOS is an auto recovery tool that allows you to restore the BIOS file when it fails or gets corrupted during the updating process. You can update a corrupted BIOS file using a USB flash drive that contains the updated BIOS file.

IMPORTANT! Prepare a USB flash drive containing the updated motherboard BIOS before using this utility.

Recovering the BIOS from a USB flash drive

To recover the BIOS from a USB flash drive:

1. Insert the USB flash drive with the original or updated BIOS file to one of the USB ports on the system.
2. The utility will automatically recover the BIOS. It resets the system when the BIOS recovery finished.

WARNING! DO NOT shut down or reset the system while recovering the BIOS! Doing so will cause system boot failure!

NOTE: The recovered BIOS may not be the latest BIOS version for this motherboard. Visit the ASUS website at www.asus.com to download the latest BIOS file.

4.9.2 ASUS EZ-Flash Utility

The ASUS EZ-Flash Utility feature allows you to update the BIOS using a USB flash disk without having to use a DOS-based utility.

IMPORTANT! Download the latest BIOS from the ASUS website at www.asus.com before using this utility.


NOTE: The succeeding BIOS screens are for reference only. The actual BIOS screen displayed may not be the same as shown.

To update the BIOS using EzFlash Utility:

1. Insert the USB flash disk that contains the latest BIOS file to a USB port.
2. Enter the BIOS setup program. Go to the **Advanced** menu > **EZ-Flash** > **Enter Ez-Flash mode**. Select Yes and then OK to auto reboot and enter EZ-Flash mode.

WARNING! Make sure to back up your Bitlocker recovery key and suspend Bitlocker encryption in the operating system before updating your BIOS.

3. Use the Up/Down arrow keys to find the USB flash disk that contains the latest BIOS, and then press <Enter>.
4. Use the Up/Down arrow keys to find the BIOS file then press <Enter>.



5. Reboot the system when the update process is done.

WARNING!

- This function can support devices such as a USB flash disk with FAT 32/16 format and single partition only.
 - DO NOT shut down or reset the system while updating the BIOS to prevent system boot failure!
-

IMPORTANT! Make sure to load the BIOS default settings to ensure system compatibility and stability. Press <F3> and select Yes to load the BIOS default settings.

Appendix

Safety information

Your Single Board Computer is designed and tested to meet the latest standards of safety for information technology equipment. However, to ensure your safety, it is important that you read the following safety instructions.

Setting up your system

- Read and follow all instructions in the documentation before you operate your system.
- Do not use this product near water or a heated source.
- Set up the system on a stable surface.
- Peripherals with extended temperature tolerance (such as industrial grade DRAM, SSD, etc.) will allow this product to be used in environments with ambient temperatures between 0°C and 60°C, with a 0.1m/s air flow.
- If you use an extension cord, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed its ampere rating.
- This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.
- This device shall not be connected to an Ethernet network with outside plant routing.

Safety precautions

Accessories that came with this product have been designed and verified for the use in connection with this product. Never use accessories for other products to prevent the risk of electric shock or fire.

Care during use

- Do not walk on the power cord or allow anything to rest on it.
- Do not spill water or any other liquids on your system.
- When the system is turned off, a small amount of electrical current still flows. Always unplug the power cord from the power outlets before cleaning the system.
- If you encounter the following technical problems with the product, unplug the power cord and contact a qualified service technician or your retailer.
 - The power cord or plug is damaged.
 - Liquid has been spilled into the system.
 - The system does not function properly even if you follow the operating instructions.
 - The system was dropped or the cabinet is damaged.
 - The system performance changes.

Lithium-Ion Battery Warning

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

NO DISASSEMBLY

The warranty does not apply to the products that have been disassembled by users



DO NOT throw the Single Board Computer in municipal waste. This product has been designed to enable proper reuse of parts and recycling. This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Check local technical support services for product recycling.

Regulatory notices

REACH

Complying with the REACH (Registration, Evaluation, Authorization, and Restriction of Chemicals) regulatory framework, we publish the chemical substances in our products at ASUS REACH website at <https://csr.asus.com/english/REACH.htm>

ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <https://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.

COATING NOTICE

IMPORTANT! To provide electrical insulation and maintain electrical safety, a coating is applied to insulate the device except on the areas where the I/O ports are located.

FCC RF Exposure Information

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels. The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid.

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

IMPORTANT! Outdoor operations in the 5.15~5.25 GHz band is prohibited. This device has no Ad-hoc capability for 5250~5350 and 5470~5725 MHz.

CAUTION! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ISED Radiation Exposure Statement for Canada

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with ISED RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting. End users must follow the specific operating instructions for satisfying RF exposure compliance.

Operation is subject to the following two conditions:

- This device may not cause interference and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Compliance Statement of Innovation, Science and Economic Development Canada (ISED)

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-003(A)/NMB-003(A)

Déclaration de conformité de Innovation, Sciences et Développement économique Canada (ISED)

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-003(A)/NMB-003(A)

Wireless Operation Channel for Different Domains

N. America	2.412-2.462 GHz	Ch01 through CH11
Japan	2.412-2.484 GHz	Ch01 through Ch14
Europe ETSI	2.412-2.472 GHz	Ch01 through Ch13

Regional notice for Singapore

Complies with
IMDA Standards
DB103778

This ASUS product complies with IMDA Standards.

Regional notice for Malaysia



HDMI Trademark Notice

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Service and Support

Visit our multi-language website at <https://www.asus.com/support>.



Our company network supports you worldwide with offices in Germany, Austria, Switzerland, the UK and the USA. For more information please contact:

Headquarters

Germany



FORTEC
GROUP

FORTEC Elektronik AG
Augsburger Str. 2b
82110 Germering

Phone: +49 89 894450-0
E-Mail: info@fortecag.de
Internet: www.fortecag.de

Fortec Group Members

Austria



FORTEC
INTEGRATED

FORTEC Integrated GmbH Office Vienna
Nuschinggasse 12
1230 Wien

Phone: +43 1 8673492-0
E-Mail: info@fortec-integrated.de
Internet: www.fortec-integrated.de

Germany



FORTEC
INTEGRATED

FORTEC Integrated GmbH
Augsburger Str. 2b
82110 Germering

Phone: +49 89 894363-0
E-Mail: info@fortec-integrated.de
Internet: www.fortec-integrated.de

Switzerland



FORTEC
SWITZERLAND

FORTEC Switzerland AG
Bahnhofstraße 3
5436 Würenlos

Phone: +41 44 7446111
E-Mail: info@fortec.ch
Internet: www.fortec.ch

United Kingdom



FORTEC
UNITED KINGDOM

FORTEC Technology UK Ltd.
Osprey House, 1 Osprey Court
Hinchingbrooke Business Park
Huntingdon, Cambridgeshire, PE29 6FN

Phone: +44 1480 411600
E-Mail: info@fortec.uk
Internet: www.fortec.uk

USA



FORTEC
UNITED STATES

FORTEC US, Corp.
87 Raynor Avenue, Unit 1
Ronkonkoma, NY 11779

Phone: +1 631 5804360
E-Mail: info@fortec.us
Internet: www.fortec.us